

2.16 Test Function

This special function is for testing single components of the control. It can be chosen immediately after power on, as long as time window has not passed.

There are two different tests integrated:

2.16.1 Customer test mode

Press temperature buttons PLUS and MINUS together.

Now "tEst" is displayed in the temperature display "Edxx" is displayed in the clock display (software edition).

Each button has another function

From the left to the right:

1. Relay 1 is switched on and the measured cavity temperature is displayed
2. Relay 2 is switched on
Keeping the button hold, the display reads the value of the analogue door input signal.
door closed => 253, door pending => 127, door open => 3
3. Relay 3 is switched on
4. Relay 4 is switched on, all symbols of both displays on
5. All 7segment digits on
6. Buzzer is switched on
7. Leave test-mode